

# The Piece Pod

## Thank you for purchasing a Piece Pod.

With a little care you will get many years of dependable service from it.

The bracket is constructed of laser cut heavy gauge 304 stainless steel. The screws are 18-8 grade 300 series..

## Parts list:

- Piece Pod 1
- #3 square drive, Robertson Bit
- (2) Stainless Steel mounting screws
- This instruction sheet

## Installation Instructions:

### Installation

- Pick your location
- Position the Piece Pod
- Level the Piece Pod before putting in the screws
- Mark screw holes
- When installing the screws, drill a slightly oversized pilot hole to avoid breakage in hardwoods such as white oak, teak and maple or in other finished materials such as a deck railing. For Softwood use a 5/32 bit, for hardwoods use a 9/64 drill bit.
- You will need a 1/4 inch hex driver tool to hold the special bit. Do not over tighten the screws when installing them. It is possible to either break the screw or distort the Pod.

### Maintenance

- No Routine maintenance, other than cleaning.
- You never need to paint your Piece Pod, but if you want a color to match your locale, the pod can be painted.
- If painting clean and degrease the pod and mask off the hinges. You may need a primer or bonding layer. Check the directions for the type of paint you plan to use.

### Cautions

- Always use eye protection when using tools.

### Removal

- Save the special bit, If you every have to remove the pod, you will need the bit and a driver.
- Just remove the screws and it will come off of the stump or railing.

Visit [www.Dynapod.com](http://www.Dynapod.com) for more information or to order more of our fine products  
You can also find information about new products and handy application notes.



**FAR Laboratories**

**P.O. Box 25**

**South Hadley, MA 01075**

800-336-9054, Fax 413-467-9393

Western Massachusetts 413-467-9262