

# The Piece Pod 2

## **Thank you for purchasing a Piece Pod.**

With a little care you will get many years of dependable service from it.  
The bracket is constructed of laser cut heavy gauge 304 stainless steel.

## **Parts list:**

- Piece Pod 2
- (8) Dual Lock Pads
- This instruction sheet

## **Installation Instructions:**

### **Installation**

- Pick your location
- Position the Piece Pod
- Wipe the bottom of the Pod with Alcohol and let dry
- Place four of the dual Lock Pads on the bottom corners
- Wipe the surface where you want to mount the Pod with Alcohol and let dry.
- Lock the four extra pads to the four on the bottom of the Pod.
- Remove the release film, and then press the pod in place.

### **Maintenance**

- No Routine maintenance, other than cleaning.
- You never need to paint your Piece Pod, but if you want a color to match your locale, the pod can be painted.
- If painting clean and degrease the pod and mask off the hinges and Dual Lock pads. You may need a primer or bonding layer. Check the directions for the type of paint you plan to use.

### **Cautions**

- Always use eye protection when using tools.

### **Removal**

- Remove any items you have stored in the pod.
- Hold the base, not the HTR and tip to a side and pull.

Visit [www.Dynapod.com](http://www.Dynapod.com) for more information or to order more of our fine products  
You can also find information about new products and handy application notes.



**FAR Laboratories**  
**P.O. Box 25**  
**South Hadley, MA 01075**  
800-336-9054, Fax 413-467-9393  
Western Massachusetts 413-467-9262